

**SKECHERS**

**Kids™**

## SHOE FIT GUIDE

### INSTRUCTIONS

Print this Guide on 8.5" x 11" (letter-size) paper scaled at 100%. Do not select "Fit to Page" or any similar option.

With a ruler, check to see if the inch marks along the right side of the Guide are accurate. If so, you printed this correctly at 100% scale.

Infant			
USA	UK	EU	CM
0	n/a	16	7
1	0	17	7.5
2	1	18	8
3	2	19	9

Toddler (1-3 years old)			
USA	UK	EU	CM
4	3	20	10
5	4	21	11
6	5	22	12
7	6	23	13
8	7	24	14
9	8	25	15
10	9	26	16

Little Kids (4-8 years old)			
USA	UK	EU	CM
10.5	9.5	27	16.5
11	10	27.5	17
11.5	10.5	28	17.5
12	11	28.5	18
12.5	11.5	29	18.5
13	12	30	19
13.5	12.5	31	19.5
1	13	32	20
1.5	13.5	33	20.5
2	1	33.5	21
2.5	1.5	34	21.5
3	2	35	22
3.5	2.5	35.5	22.5

Big Kids (8-10 years old)			
USA	UK	EU	CM
4	3	36	23
4.5	3.5	36.5	23.5
5	4	37	23.5
5.5	4.5	37.5	24
6	5	38	24
6.5	5.5	39	24.5
7	6	40	25
8	7	41	26

10"

9"

8"

7"

6"

5"

4"

3"

2"

1"

**PLACE HEEL AT ZERO MARKER**

If the child's foot goes past the dotted line, a wide-width style may be a better fit.